

SOCOGEL A0203 BLUE SOCOGEL B0202 / B0202 BLUE (PEN)

SOL-GEL BEFORE PAINTING
FOR TOUCH UP

Application Guide – Guide d'Application

SOL-GEL PREPARATION (30 ml kit)



1. Open the pouch.



2. Two component product:
- Part C
- Part G / E / EC



3. Dispense part C into part G / E / EC:
small bottle into bigger bottle.



4. Mix or shake thoroughly for a **minimum of 30 seconds**.

A touch up pen.

TOUCH-UP PEN PREPARATION



1. Open the touch-up pen and remove the cap and the pad.



2. Pour 30 ml of
SOCOGEL A0203
SOCOGEL B0202
SOCOGEL B0202 BLUE



3. Close the pen by replacing the pad and cap.
Write down the "mix date" and the "mix time".

Wait **30 min** before using



4. Initiate the pen by pressing the pen pad several times on the surface



5. Use the pen.

DON'T DO

- All sol-gel kits **MUST** be used in a single operation, **NEVER** mix the parts only partially, they must always be mixed completely.
- After opening and mixing, the solution must be used before end of pot life.
- Do not refill the pen after use. At the end of the pot life, the pen must be disposed of without being reused. Do not store opened packaging or filled pens.